

## 4 Troubleshooting

**Notes:** 1. Before troubleshooting, setup the PC's display as below.

- Resolution: 1024 x 768
- H-frequency: 48 kHz
- V-frequency: 60 Hz


2. If no picture appears, make sure the power cord is correctly connected.

3. Check the following circuits.


- No raster appears: SMPS PCB, Main PCB
- 14V develop but no screen: Main PCB
- 14V does not develop: SMPS PCB

4. If you push and hold the "EXIT" button for more than 5 seconds, the monitor automatically turns back to the factory preset.


### 4-1 No Power



## 4-2 No Video



## WAVEFORMS



**4-3 No OSD**